

LA-UR-15-28285

Approved for public release; distribution is unlimited.

Title: Introduction to neutron rem meters

Author(s): Mclean, Thomas Donaldson

Intended for: Neutron training class at CSU (Fort Collins, CO) Oct27-29 2015

Issued: 2015-10-22

Disclaimer:

Los Alamos National Laboratory, an affirmative action/equal opportunity employer, is operated by the Los Alamos National Security, LLC for the National Nuclear Security Administration of the U.S. Department of Energy under contract DE-AC52-06NA25396. By approving this article, the publisher recognizes that the U.S. Government retains nonexclusive, royalty-free license to publish or reproduce the published form of this contribution, or to allow others to do so, for U.S. Government purposes. Los Alamos National Laboratory requests that the publisher identify this article as work performed under the auspices of the U.S. Department of Energy. Los Alamos National Laboratory strongly supports academic freedom and a researcher's right to publish; as an institution, however, the Laboratory does not endorse the viewpoint of a publication or guarantee its technical correctness.



Introduction to neutron rem meters

Tom McLean, LANL

CSU neutron class
Fort Collins, CO
Oct. 27-29 2015

UNCLASSIFIED

Introduction: talk outline

- Discussion (brief) of neutron remmeters
 - Gas proportional counters
 - $^3\text{He}(n,p)\text{T}$ and $^{10}\text{B}(n,\alpha)^7\text{Li}$ based instruments
 - Proton recoil counters
 - Activated foil-based instruments
 - Scintillator-based instruments

UNCLASSIFIED

Slide 2

^3He and ^{10}B gas-based counters

- ^{10}B
 - Uses BF_3 gas usually enriched to ~95% ^{10}B
 - Limited to gas pressures of about 2atm maximum
 - Excellent gamma rejection properties
 - Boron-coated counters also used with a counting gas
- ^3He
 - Often used with high Z gas to promote energy deposition
 - High pressure operation possible
 - Limited availability – DHD seeking alternatives
 - Very good gamma discrimination
 - Chemically inert (unlike BF_3)

UNCLASSIFIED

Slide 3

Gas proportional counters

- Secondary charged particles (p , α) ionize surround gas
- Electrons drift towards +ve charged central anode wire
- Electrons gain additional KE as electrical field increases
 - Generating additional electrons through collisions
- The overall gas multiplication effect gives rise to an enhanced anode current that is proportional to the initial energy deposited by the neutron interaction.

UNCLASSIFIED

Slide 4

Gas proportional counters

- An electronics assembly converts charge to a proportionally sized voltage pulse.
 - Electronic package also supplies the necessary bias voltage
- Electronics can be housed in an external rate meter or integrated into the detector housing.
- If voltage pulse exceeds a user-set discriminator level it is accepted as a neutron event.
- A calibration factor is then applied to convert counts to dose
- Typically two modes of operation: scalar and rate mode

UNCLASSIFIED

Slide 5

Instruments based on thermal neutron capture




- Energy response of bare counter is unacceptable.
 - Response is highest in region where dose per neutron is lowest and *vice versa* .
 - Solution is to modify the incident spectrum to improve the instrument response
-
- Adding a shell of PE gives a more tissue-like response
 - 9" diameter sphere is typically used
 - Cd or B-loaded PE internal shell often used as well
 - Perforating this shell further improves energy response
 - But there is a weight penalty

UNCLASSIFIED

Slide 6


Comparison of neutron capture x-sections with H*(10) curve



UNCLASSIFIED

Slide 7

Instruments based on thermal neutron capture



Hankin's design



Anderson Braun design

Typical sensitivity: 40cpm per mrem/h per atm.

Energy response: no better than $\pm 30\%$

Weight: no less than 20lbs

Resolving time $\sim 5-10 \mu\text{s}$

UNCLASSIFIED



Canberra DiNeutron :
Uses two PE-moderated detectors

Instruments based on thermal neutron capture: high-energy neutron response



Thermo's
SWENDI II

High energy response boosted by adding high Z shell (e.g. Bi or W) to generate additional neutrons via (n, xn) reactions.

Typical sensitivity: 300cpm per mrem/h per atm.

Energy range: extended from 20MeV to 5 GeV

Weight: no less than 30lbs




HPI 6060

UNCLASSIFIED

Slide 9

Instruments based on thermal neutron capture: energy response



UNCLASSIFIED

Slide 10

Fuji NSN3 remmeter




- Two gas-based detectors in single sealed gas proportional counter.
 - Thermal detector based on $^{14}\text{N}(n,p)^{14}\text{C}$ rxn $E_p=0.626$ MeV
 - 0.98 atm of N_2
 - Fast neutron detector based on proton recoil
 - 3.98 atm of CH_4
 - Total volume = 1.5 l
 - Total weight = 5.1 lbs

UNCLASSIFIED

Fuji NSN3 remmeter

- Uses a minimal amount of PE moderation
- Incorporates an MCA to obtain pulse height spectrum.




UNCLASSIFIED

Slide 12

Fuji NSN3 remmeter


- Pulse height spectrum is analyzed to yield neutron dose using a single optimized calibration constant.
- Energy response data:



UNCLASSIFIED

Slide 13

Fuji NSN3 remmeter: LANL data




UNCLASSIFIED

Slide 14

Fuji NSN3 remmeter

- Energy response of $\pm 20\%$ claimed
- Sensitivity about same as NRD
- Gamma rejection is not as good as BF_3 or ^3He -based instruments



- Problem with transporting due to high-pressure flammable gas

UNCLASSIFIED

Slide 15

Tissue equivalent counter



HPI REM500


- Based on lineal energy transfer in tissue equivalent gas surrounded by TE plastic.
- $\text{Lineal energy} = \text{deposited energy} / \text{Avr. chord length of spherical gas cell.}$
- MCA used to obtain lineal energy spectrum.
- Quality factor based on lineal energy corresponding to each channel is applied to the counts in that channel to calculate dose equivalent

UNCLASSIFIED

Slide 16

Tissue equivalent counter

- Low energy events overlap gamma spectrum
- Sensitivity is relatively low at 8 cpm per mrem/h
- But, in principle, gives best possible estimate of dose equivalent
- Weight is only 5lbs



UNCLASSIFIED

Slide 17

Instrument performance comparison

Table 4. Responses of neutron detectors in several scattered neutron fields.

Field Detector	[A]	[B]	[C]	[D]	[E]	[F]	[G]
NG-2	0.748	0.676	0.617	0.591	0.520	0.705	0.602
ESP2/NRD	0.690	0.666	0.609	0.594	0.571	0.741	0.620
Ludlum	0.621	0.623	0.606	0.578	0.546	0.696537	0.646
REM-500	0.605	0.584	0.557	0.526	0.463	0.466	0.354
Dineutron	0.663	0.217	0.648	0.393	0.206	0.641	0.299

B.H. Kim¹, J.L. Kim¹, S.Y. Chang¹, J.K. Chang¹, G. Cho²

¹Korea Atomic Energy Research Institute, P.O.Box105, Taejon, 305-600, Korea

²Department of Nuclear Engineering,

Korea Advanced Institute of Science and Technology, Taejon, 305-701, Korea

UNCLASSIFIED

Slide 18

Pulsed field performance


- Accelerator fields are frequently pulsed resulting in high instantaneous neutron fluence and dose rates.
- Neutron rem meters using PE-moderators are somewhat immune due to the time required to thermalize fast neutrons (typically 50-100 μ s) – effectively lengthening the pulse.
- But there are limitations on the effectiveness of the PE moderator and other means of neutron dose measurements are required
- E.g. ion chambers in current mode
 - Boron-lined chambers or chambers with TE walls and gas

UNCLASSIFIED

Slide 19

Pulsed field performance

- The HPI 2080 (“Albatross”) is designed to operate in pulsed (and static) fields.
- Standard PE-moderator approach
- But uses two GM tubes
 - One surrounded by Ag foil the other with an equivalent mass thickness of tin.
 - The Ag foil is activated through TNA
 - Its GM tube counts subsequent beta decay
 - The second GM compensates for the gamma background



^{108}Ag ($t_{1/2} = 145$ s)

^{110}Ag ($t_{1/2} = 25$ s)

UNCLASSIFIED

Pulsed field performance

- Sensitivity is relatively low at 30 cpm per mrem/h
- Energy response similar to PE-moderated instruments
- Weight is 25lbs
- A high-energy enhanced response instrument version (“Eagle”) is also available



UNCLASSIFIED

Slide 21

Scintillator-based instruments

- Not in wide spread use due gamma discrimination not being nearly as good as $^{10}\text{BF}_3$ and ^3He gas counters.
- Gas-based instruments also more rugged due to PE shell
- But scintillation-based instruments don't necessarily require use of a heavy PE moderator.
 - A definite ergonomic advantage

UNCLASSIFIED

Slide 22

Scintillator-based instruments: PRESCILA


- Proton Recoil Scintillator Los Alamos
- Developed at LANL and commercialized by Ludlum Inc.
- Utilizes a dual detector approach (like the Fuji NSN3) for fast and thermal neutron detection.
- Weight = 6lbs
- Benefited from extensive Monte Carlo modelling to optimize design



UNCLASSIFIED

Slide 23

Scintillator-based instruments: PRESCILA




Eljen EJ-410P
ZnS(Ag)-filled
rings
surrounded by
lucite

- Fast detector comprised of 5 EJ-410P scintillators
 - Recoil protons generated in lucite excite ZnS(Ag)
 - Light emission collected by lucite light guide and detected by central PMT
- Thermal channel is comprised of a ${}^6\text{LiF}+\text{ZnS}(\text{Ag})$ scintillator
 - ${}^6\text{Li}$ content commensurate if fast detector response

UNCLASSIFIED

PRESCILA: Dose response and comparison



PRESCILA under response where fast and thermal detectors overlap

UNCLASSIFIED

Slide 25

PRESCILA

- Limitation of using a single PMT creates a minimum dose response where the fast and thermal energy ranges overlap (same effect seen in the Fuji probe)
- Sensitivity ~ 100 cpm per mrem/h
- Gamma breakthrough observed above 50 mR/h
 - Pb lining later added to reduce gamma response
- Not currently in use at LANL



UNCLASSIFIED

Slide 26

Other scintillators

- Liquefied rare gases
- ^6Li -based glasses
- $\text{Cs}_2\text{LiYCl}_6:\text{Ce}$ (CLYC)

UNCLASSIFIED

Calibration of neutron rem meters

- Require NIST-traceable source or instrument cal.
 - ^{252}Cf or $^{241}\text{AmBe}$ most often used

- Need to characterize neutron field (dose rate vs distance from source)
 - Measurements and/or Monte Carlo calculations

- Instruments should be calibrated in a field which gives the most conservative calibration factor
 - Function of instrument energy response and the workplace field

UNCLASSIFIED

Slide 28

Some points to consider in selecting a neutron rem meter

- Energy response
- Angular response
- Neutron sensitivity
- Gamma rejection
- Ergonomics
- Calibration source
- Reliability
- Pulsed field performance
- Ease of:
 - use, maintenance/repair and calibration
- Transportation issues
 - hazardous gases and/or high pressures

UNCLASSIFIED

Slide 29