

LA-UR-16-22446

Approved for public release; distribution is unlimited.

Title: LANL evaluation of the Fuji NSN3 neutron remmeter

Author(s): Mclean, Thomas Donaldson
Justus, Alan Lawrence
Seagraves, David Troy
Voss, James Thomas
Lowe-Henderson, Nancy Anne

Intended for: Health Physics Instrumentation Committee Meeting,
2016-04-11/2016-04-13 (Las Vegas, Nevada, United States)

Issued: 2016-04-11

Disclaimer:

Los Alamos National Laboratory, an affirmative action/equal opportunity employer, is operated by the Los Alamos National Security, LLC for the National Nuclear Security Administration of the U.S. Department of Energy under contract DE-AC52-06NA25396. By approving this article, the publisher recognizes that the U.S. Government retains nonexclusive, royalty-free license to publish or reproduce the published form of this contribution, or to allow others to do so, for U.S. Government purposes. Los Alamos National Laboratory requests that the publisher identify this article as work performed under the auspices of the U.S. Department of Energy. Los Alamos National Laboratory strongly supports academic freedom and a researcher's right to publish; as an institution, however, the Laboratory does not endorse the viewpoint of a publication or guarantee its technical correctness.



Los Alamos

NATIONAL LABORATORY

— EST. 1943 —



 **Los Alamos**
NATIONAL LABORATORY
— EST. 1943 —

Delivering science and technology
to protect our nation
and promote world stability



LANL evaluation of the Fuji NSN3 neutron remmeter



**Tom McLean, Alan Justus,
Dave Seagraves, Tom Voss
and Nancy Lowe-Henderson**

HPIC Meeting
April 11-13 2016, Las Vegas, NV

LANL evaluation of the Fuji NSN3 neutron remmeter



**Tom McLean, Alan Justus,
Dave Seagraves, Tom Voss
and Nancy Lowe-Henderson**

HPIC Meeting
April 11-13 2016, Las Vegas, NV

Talk outline

- Introduction
- Evaluation data
- Summary



Selected Instrument properties


| | |
|--------------------------------|--|
| Detector type | Gas proportional counter |
| Weight | 2.3 kg (5.1 lbs) |
| Gas Filling | CH ₄ (4 atm) + N ₂ (1 atm) |
| Chamber volume | 1.4 L |
| Nominal sensitivity | 21 cpm/μSv (210 cpm/(mrem/h)) |
| Dose rate range | 0.1 – 1000 mrem/h (5 decades) |
| Dose range | 0.01 – 1000 mrem (6 decades) |
| Conformity with H*(10) ICRP-74 | ±20% from thermal to 15 MeV |
| Gamma interference | Reads 0.8 mrem/h in a 1R/h field |
| Power options | 6 x (AA alkaline or Ni-MH) or 12v AC |
| Data logging | 1200 records uploaded via USB |

N3NS probe



Navigate menu options using just 3 buttons

25 cm



Introduction: principles of operation


- Chamber is filled with mixture of methane (4 atm.) and Nitrogen gas (1 atm.)
- Low energy response (<10 keV) utilizes the following reaction
 - $^{14}\text{N}(n,p)^{14}\text{C}$ $E_p = 626 \text{ keV}$ (range of about 2mm in the gas mixture)
- High energy response (>400keV) relies on proton recoil
 - Overlap with gamma-induced signal determines minimum energy
 - Wall effects determine the upper limit
- The relative amounts of the two gases and their respective reaction cross-sections determine the overall neutron response
 - This response should ideally mimic the $H^*(10)$ dose curve

Thermal response

A threshold setting of 400 keV is used

• Energy resolution


$^{14}\text{N}(n, p)^{14}\text{C}$: 626keV



- The pulse height of the thermal peak is fixed but its magnitude varies with neutron energy (i.e. reaction cross-section)


Monoenergetic neutron response at relatively low energies

- Neutrons below the threshold energy (e.g. 144 and 250 keV) are only observable via the thermal channel
- Higher energy neutrons show classic proton recoil energy distribution




Monoenergetic neutron response at relatively high energies (wall effects become increasingly evident)

- Introduction



NSN3 energy response compared with H*(10)



NSN3 energy response

- Overall instrument response is not an ideal match with $H^*(10)$
- Instrument software compensates by filling the region below 0.5 MeV based on typical power plant spectra and the counts observed in the 1-2 MeV window
- Dose software also uses three ROIs to calculate individual contributions to total dose
 - An advantage of the pulse height approach
 - Utilizes the G-value method to get optimum scaling factors for each ROI

NSN3 evaluation: neutron dose rate measurements

- Measurements made on the neutron reference range in the Central Health Physics Calibration Facility at TA36.
 - Bare ^{252}Cf , D_2O -moderated Cf and AmBe measurements recorded
- NSN3 calibrated using AmBe

AmBe data

| AmBe source | Distance (cm) | CTV dose rate (mrem/h) | NSN3 reading (mrem/h) | Normalized response |
|--------------------|----------------------|-------------------------------|------------------------------|----------------------------|
| 8969NK | 50 | 104.4 | 100.13 | 0.959 |
| 8969NK | 100 | 27.46 | 27.28 | 0.993 |
| 8969NK | 150 | 12.95 | 12.61 | 0.974 |
| 8969NK | 200 | 7.815 | 7.66 | 0.980 |

NSN3 evaluation: neutron dose measurements

Bare ^{252}Cf data

| ^{252}Cf source | Distance (cm) | CTV dose rate (mrem/h) | NSN3 reading (mrem/h) | Normalized response |
|--|----------------------|-------------------------------|------------------------------|----------------------------|
| Z3899 | 50 | 1319 | 1281 | 0.971 |
| Z3899 | 100 | 350.1 | 331.5 | 0.947 |
| Z3899 | 150 | 166.8 | 155.3 | 0.931 |
| Z3899 | 200 | 101.6 | 94.81 | 0.933 |
| 1899 | 50 | 77.78 | 74.76 | 0.961 |
| 1899 | 100 | 20.65 | 19.92 | 0.965 |
| 1899 | 150 | 9.838 | 9.44 | 0.960 |
| 1899 | 200 | 5.991 | 5.67 | 0.946 |


NSN3 evaluation: neutron dose measurements

D₂O-moderated ²⁵²Cf data

| ²⁵²Cf source | Distance (cm) | CTV dose rate (mrem/h) | NSN3 reading (mrem/h) | Normalized response |
|--------------------------------|----------------------|-------------------------------|------------------------------|----------------------------|
| Z3899 | 50 | 317.8 | 260.8 | 0.821 |
| Z3899 | 100 | 85.03 | 66.49 | 0.782 |
| Z3899 | 150 | 41.1 | 32.48 | 0.790 |
| Z3899 | 200 | 25.4 | 20.07 | 0.790 |
| 1899 | 100 | 5.016 | 3.73 | 0.744 |
| 1899 | 150 | 2.424 | 2.33 | 0.961 |


NSN3 vs NRD normalized dose response

- NSN3 response compared with NRD using PE-moderated Cf (spheres with 1",2",3" and 4" wall thicknesses) in addition to previously mentioned sources.
- All data collected at distance of 1m from each source.




NSN3 angular response

- NSN3 angular response in vertical and horizontal directions using bare Cf source.
- Data normalized at 0°.
- Agreement with Fuji supplied-data.




NSN3 gamma response

- Data again collected at TA36 using the gamma (^{137}Cs) calibration facility.
- Our results fully consistent with data supplied by Fuji.




NSN3 field data

- NSN3 readings compared with “official” NRD measurements at TA54.
- Dose rates averaged over 1 minute count times.
- RO-20 data recorded at same time.
- Most NSN3 readings within -20% to +10% of NRD (implying average energies > 1MeV).



NSN3 field data

- Ratio of NSN3 and NRD dose rates to the RO-20 readings were compared.
- Both ratios are in very good agreement.
 - Implies that interference from gamma exposure rates of up to 80 mR/h have no observable effect on NSN3 readings (agrees with gamma response data shown previously).



Feedback from field

- Instrument was easy to use and menu-driven user interface was intuitive.
- Instrument's light weight was a major ergonomic advantage over the NRD.
- Display was readily readable indoors but difficult in sunlight.
- No non-rad interferences (microphonics, RF, etc ...) were noticed.
- Supplied shoulder harness allows hands-free operation.

Feedback from field and other comments

- Display assembly is fragile and was prone to damage (twice).
- Uploading of data from instrument to PC was hit and miss.
 - Repeated efforts required to get all data transferred
 - Incorrect dates logged (e.g. “1899”)
- Pressurized gas considered “hazardous” and requires a DOT special permit for shipping purposes.
- At LANL, a material-of-trade exemption allows transport between Technical Areas
 - Only requirements are that instrument must be labelled and shipped in its protective case and that driver be made aware of requirement.
- Deployment in some facilities an issue due to flammable gas filling.

The End